Sony A6300/A6400 Cheat Sheet

Zoom the lens in and out with this switch

Mode change dial

Shutter release button

On/off switch

Hotshoe for external flash

Formatting memory card done via the menu system look for the wrench icon and scroll through

Pop-up flash

Digital Viewfinder

Main control dial for shutter speed or aperture depending on shooting mode

Video record button

Secondary control dial for aperture or shutter speed depending on shooting mode

Battery and SD Card found in compartment on the underside of camera here

Tilting LCD screen for live view/menus

Photo/video playback button