

Presenting with Remote Control

On the projector

- 1) Connect the **blue VGA Cable** and “**USB Type B**” cable (black wire with blue head and screws)




- 2) Connect the power adapter to bottom left



On the laptop

- 3) For Map laptop, connect the **miniDisplay to VGA adapter** to the laptop on the left side, then connect the blue VGA cable to the adapter
- 4) For PC laptop, connect the blue VGA cable directly to the laptop. No adapter is needed.
- 5) Connect the USB cable to the laptop on the left side as well



After wiring is setup.

Point the remote at the projector for the following steps:

- 1) Select Menu (located on the bottom left side of the remote)
- 2) Look at projecting screen and scroll down to Extended
- 3) Hit the right arrow bottom on the remote.
- 4) Scroll down to USB type B
- 5) Press Enter (located in the middle of the arrow buttons)
- 6) Scroll Down to Wireless Mouse
- 7) Press Enter
- 8) Press Menu-this removes the menu from the display

Look at your computer:

- 1) Open your presentation in PowerPoint
- 2) Go into presentation mode in PowerPoint
- 3) Click the "mirror show" located in the top right of the PowerPoint window for setting for two displays
- 4) Click from start
- 5) On the remote press enter to move forward
- 6) To move backward-Press esc and scroll using the arrows and click previous.