


# Sennheiser XSW-D Handheld Cheat Sheet

Handheld microphone, note ours looks slightly different

Our equipment does not come with the stand clip mount

Both receiver and transmitter charge via USB-C plugged into the underside



Our microphone does not have a switch

Plug the transmitter into the bottom of the microphone

Both receiver and transmitter must be turned on